STANDARD STYLE TRADITIONAL MAILBOX H4610 & H4620 INSTALLATION INSTRUCTIONS

Thank you for selecting the Standard Style Traditional Mailbox from National Mailboxes. Made of electro-galvanized steel with a durable powder coated finish, the Standard Style Traditional Mailbox will provide years of maintenance free service. While the hole locations differ, the mounting method is the same for both the H4610 and H4620 mailboxes.

Mounting Mailbox to a Flat Wall


- 1. The installation fasteners are not provided due to the variation in wall types to which the mailbox might be mounted. Select fasteners and anchors appropriate for the type of wall.
- 2. Mounting access is provided by opening the lid.
- 3. Where possible, it is best to shield the mailbox from direct weather conditions.
- 4. Contact your local U.S.P.S. office for the required height of the mailbox on the wall.
- 5. Holding the mailbox aligned horizontally in the mounting position, mark on the wall the position of the 4 mounting holes in the back wall of the mailbox. The 4 dimpled holes are the mounting holes.
- 6. Attach the mailbox to the wall using the appropriate fasteners.

Attaching Hooks to Mailbox (optional)


Using the four 1/4" long screws (provided), attach the magazine hooks to the mailbox by inserting each hook through the slots at the base of the mailbox.

Cleaning

Use a non-abrasive mild cleaning solution and a soft cloth. Do not use harsh chemicals on or around this product.



4620 Traditional Mailbox - Vertical Style





Installation instructions are provided as general guidelines. It is advised that a professional installer be consulted. National Mailboxes assumes no product assembly or installation liability.